# SPEED-RAK® MOUNTING INSTRUCTIONS

Speed-Raks® may be mounted in a SINGLE ROW or DOUBLE ROW. Any single Speed-Rak® will mount to the front of another single Speed-Rak® as shown below.

#### **CONTENTS**

- 2 #10 x 3/4 Sheet Metal Screws
- 2 #10 Flat Washers
- 2 10-32 x 3/8 Machine Screws
- 2 10-32 Acorn Nuts


## SINGLE SPEED-RAK® INSTALLATION:

## **SINGLE MOUNTING:**

1. Attach wood or other spacer to sink (shown to the right). This keeps Speed-Rak® firmly mounted. Make sure there is no leaning.


**HANGER STRAP MOUNTING:** (Hanger Straps fit all S/S Model Speed-Raks<sup>®</sup>)

- 1. Slip 2 Hanger Straps onto Speed-Rak®.
- 2. Place over edge of sink.
- 3. DO NOT mount a double row using hanger straps. It may be unstable.



## **DOUBLE SPEED-RAK® INSTALLATION:**

These screws are for additional support.



Worldwide Headquarters: P.O. Box 53006 Oklahoma City, Oklahoma 73152-3006 (405) 475-5600 • FAX (405) 475-5607 1-800-654-8210 website: www.carlislefsp.com European Distribution Center: Edisonstraat 84, P.O. Box 110 6900 AC Zevenaar, The Netherlands Tel +31/(0)316-596550 • Telex 45642 FAX +31/(0)316-340168 #104T103018 Rev.3/02

